



ICOP TECHNOLOGY INC.,
昭營科技股份有限公司

Is there an easy way to support the non-VGA system with Vortex86DX?

Yes, you can use Console Redirection through COM port and use your PC to monitor this non-VGA system. To use this, you should enable the "Remote Access Control" and choose the proper COM port setting (115200, n, 8, 1). On your PC side, you should open the "Hyper Terminal" with proper setting (115200, n, 8, 1). Then you can easily change the BIOS setting and update the software on this non-VGA Vortex86 system from your PC.

For more technical support, please visit <http://www.dmp.com.tw/tech/> or mail to tech@dmp.com.tw
